

For ConTech Lighting Quadris LED Wet Location Wall Sconce: WS075L and WS085L Series

INSTALLATION PROCEDURES

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved. Housing can NOT be installed in direct contact with insulation. Do not install insulation within 3" of fixture sides or wiring compartment, nor above fixture in such a manner to entrap heat.

INSTALLATION:

- Turn off power.
- Remove the four (4) screws from the front of the housing, then remove the housing cover.
- Attach mounting bracket to the outlet box with the screws provided.
- Screw the threaded pipe to the mounting bracket until only 1/2" of the threaded pipe remains exposed. Thread hexnut onto threaded pipe until it tightens against the mounting strap.
- Make the wire connections. Connect the white wire to neutral and the black wire to line.

NOTE: Some units have two additional wires, gray and purple. If present, these wires are used to connect the fixture to a 0-10V/Mark 7 dimming system. If not used, these wires must be capped off.

- Push fixture to the wall, carefully passing the threaded pipe through the mounting hole.
- After positioning fixture with the correct end up, tighten fixture to the wall with the second hexnut. While tightening the hexnut, be extremely careful not to touch any of the yellow LEDs surrounding the mounting hole. The use of a tubular hex key/socket wrench is recommended for best results and quickest installation.
- Replace the housing cover, rubber washer and screws.
- Remove the top and bottom screws from the housing.
- Position faceplate over the housing and attach with the screws removed in the previous step.

IMPORTANT SAFETY INSTRUCTIONS:

- Read all the instructions before installation. Save instructions for later use.
- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE
 CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED
- MIN 60°C SUPPLY CONDUCTORS
- Turn off power at fuse or circuit breaker box before installation or before doing any maintenance work.
- Product must be grounded to avoid potential electric shock and any other potential hazards.
- Product must be mounted in locations and at heights and in a manner consistent with its intended use, and in compliance with National Electrical Code and local codes. Use of accessory equipment is not recommended.
- Installing contrary to instructions may cause unsafe conditions.
- Warning: Risk of fire. Consult a qualified electrician before installation.
- To avoid hazards to children, account for all parts and properly dispose of all packing materials.
- Call the Technical Support department at ConTech Lighting with any installation questions: 847.559.5500.

All specifications subject to change without notice.