



For ConTech Lighting Single Circuit Track Fixtures: CTL84 Series

Beam Position (Figure 1)


- To move the beam from the Wide Beam position (retracted) to Narrow Beam position (elongated), simply pull the internal sleeve outward away from the fixture base.
- To move the beam from the Narrow Beam position (elongated) to Wide Beam position (retracted), simply push the internal sleeve intward toward the fixture base.

Single-Circuit Fixture Polarity Alignment (Figure 2)


- Track polarity is indicated by a grooved polarity line that runs the entire length of the track.
- All fixtures have indicator arrows designed to point to the track polarity line.
- To install:
 - A. Insert the fixture contacts into the track channel.
 - B. Retract the track latch by gently pulling down.
 - C. Rotate the adapter 90° so that the polarity arrow points to the polarity line on the track.
- When the fixture is installed, the track latch will lock the fixture into the track.
 NOTE: All latches should face the same direction after installation.
- Once the fixutre is installed into the track, move the ON/OFF switch to the ON position.
- On fixtures designed for use with MR16 lamps, ConTech Lighting provides a clear, tempered safety glass. This safety glass should only be used with open MR16 lamps, and not used with MR16 lamps that contain an integral glass lens.


IMPORTANT SAFETY INSTRUCTIONS:


- Read all the instructions before installation. Save instructions for later use.
- Turn off the power at fuse or circuit breaker box before installation or any maintenance work.
- Wear rubber soled shoes and work on a sturdy wooden or non-conductive ladder.
- Product must be mounted in locations and at heights in compliance with National Electrical Code and local building codes. For indoor use only.
- Do not exceed the nominal supply voltage or amperage ratings.
- Installing contrary to instructions may cause unsafe conditions.
- Warning: Risk of fire. Most dwellings built before 1985 have supply wire rated at 60°C.
 Consult a qualified electrician before installation.
- To avoid hazards to children, account for all parts and properly dispose of all packing materials.
- Call the Technical Support department at ConTech Lighting with any installation questions.



Narrow Beam Position







All specifications subject to change without notice.